

## Curing Aid

### SURFACE PREPARATION

- Apply to the concrete as soon as tamping, trowelling or floating has been completed, or immediately after the formwork is stripped.
- Ensure that there is no free water on the surface at the time of application.

### APPLICATION

- On horizontal or vertical surfaces, apply by spray at a rate of 5.5–6m<sup>2</sup> per litre.
- After any shuttering is struck, thoroughly dampen the surface with clean water, then apply Curing Aid by spray at 5.5–6m<sup>2</sup>/litre.
- Avoid ponding of Curing Aid as this may result in a glaze following drying.

### CURING

If there is excessive heat and/or a drying wind, it is recommended that polythene sheeting be fixed tightly to the surface immediately after applying the Curing Aid.

### PRECAUTIONS

- Do not place when the substrate temperature is below 5°C or when the ambient temperature is 5°C and falling.
- Protect from frost.
- Avoid contact with glass or paintwork.